

街角点座標及街区面積計算簿

街区番号 (No. 242)

点	方向角(A)	距離(S)	Cos A		sin A		x	y	(3) 複緯距	(4) 複經距	(1) × (4)	(2) × (3)
			(1) SCos A	(2) Ssin A								
A1							578.829	633.548				
A2	32 30 22	10.22	0.1027	1.1577	5715.792	6339.105						
1	17 10 24	10.247	0.1790	0.1026	5706.102	5336.109						
B1	17 8 56	27.642	0.1746	0.2862	5422.256	5310.267						
B2	62 21 48	0.419	1.1586	0.1029	5620.070	5307.238						
C1	107 20 65	20.182	0.1017	1.1265	5626.607	5287.976						
C2	150 46 57	0.301	0.1042	1.1498	5629.729	5286.476						
D1	127 10 35	97.254	0.1490	0.2898	5720.219	5315.074						
D2	262 24 35	0.424	1.1586	0.1025	5724.805	5318.409						
A1	287 19 55	20.060	0.1976	1.1459								
点検点座標計算										Σ		
										倍面積		
										面積	2547.728	

不二測量株式会社

換地面積計算用紙 (不正形用)

角頂	夾角	辺長	方位角	緯距		経距		複経距	倍面積		町地名番
				+	-	+	-		+	-	
	(上)										
1											
2		14.552	17 2 56	13.905		4.291					
16		11.229	107 5 48		3.575	11.298					
15		14.544	197 14 31		13.293	4.319					
1		11.299	287 4 5	3.463		11.229					
					17.212	17.212	14.529	14.529			
										21.817	

不二測量株式会社

換地面積計算用紙 (不正形用)

角頂	夾角	辺長	方位角	緯距		経距		複経距	倍面積		町地名番
				+	-	+	-		+	-	
	0		0								
3											
4		14.505	17 2 56	13.860		4.276					
18		11.263	107 2 53		3.578	11.342					
17		14.599	107 13 53		13.848	4.295					
3		11.262	7 2 57	1 10	3.416		11.323				
					7.326	7.326	15.618	15.618			
										171.579	

不二測量株式会社

換地面積計算用紙 (不正形用)

角頂	夾角	辺長	方位角	緯距		経距		複経距	倍面積		町地名番
				+	-	+	-		+	-	
	(2)										
6											
B1		14.020	17 25 56	13.856		4.152					
B2		13.419	62 21 48	11.586		3.038					
7		9.626	107 20 46		2.833	8.072					
20		16.578	197 14 0		15.728	4.892					
6		11.907	287 15 0	11.531		11.371					
				18.471	18.471	16.250	16.250				
										198.574	

不二測量株式会社

換地
面積
計算
用紙
(不正形用)

角頂	夾角	辺長	方位角	緯距		経距		複経距	倍面積		町地名番
				+	-	+	-		+	-	
	00		0 0 0								
20											
7		14.578	17 14 0	15.738		4.084					
C1		10.678	197 20 25		3.105	10.192					
C2		3.391	153 46 57		3.262	1.548					
8		10.998	197 10 25		10.978	4.134					
20		13.024	207 14 58	0.862			12.638				
				19.600	19.600	16.572	16.572				
										211.464	

不二測量株式会社

換地面積計算用紙 (不正形用)

角頂	夾角	辺長	方位角	緯距		経距		複経距	倍面積		町地名番
				+	-	+	-		+	-	
	021										
19											
20		15.475	104.02	14.784		4.584					
8		10.024	107.145		0.182	12.438					
1		15.464	197.100		14.774		4.566				
19		10.039	287.114		0.265		12.456				
				18.636	18.636	17.022	17.022				
										201.688	

不二測量株式会社

換地面積計算用紙 (不正形用)

角頂	夾角	辺長	方位角	緯距		経距		複経距	倍面積		町地名番
				+	-	+	-		+	-	
	4)										
18											
19		12.472	114° 21'	10.822		4.288					
9		10.009	107° 11' 48"		3.805	12.456					
10		12.639	107° 10' 35"		10.795	4.264					
18		10.054	207° 0' 9"	3.828		12.480					
				17.660	17.660	16.744	16.744				
										188.500	

不二測量株式会社

換地面積計算用紙 (不正形用)

角頂	夾角	辺長	方位角	緯距		経距		複経距	倍面積		町地名番
				+	-	+	-		+	-	
	(2)										
17											
18		12.599	17 10 60	12.228		4.295					
10		12.264	107 0 9		3.228	12.480					
11		12.842	107 10 35		12.246	4.280					
17		12.268	207 1 29	3.226		12.845					
				7.674	7.674	14.770	14.770				
										188.222	

不二測量株式会社

換地面積計算用紙 (不正形用)

角頂	夾角	辺長	方位角	緯距		経距		複経距	倍面積		町地名番
				+	-	+	-		+	-	
	(E)										
15											
16		14.546	7 16 7	13.882		4.310					
12		10.022	107 6 51		0.847	12.504					
10		12.538	117 10 25		10.870	4.394					
15		10.047	207 4 51	0.848		12.520					
					7.737	17.707	16.814	16.814			
										170.260	

不二測量株式会社

換地面積計算用紙 (不正形用)

角頂	夾角	辺長	方位角	緯距		経距		複経距	倍面積		町地名番
				+	-	+	-		+	-	
	° ' (面)		° ' "								
14											
15		12.7201	17 12 51	12.159		3.771					
13		13.097	107 4 5		3.840	12.529					
D1		10.373	107 10 35		2.910	3.664					
D2		12.424	242 24 35		1.526	3.035					
14		10.677	287 19 55	3.181		10.192					
				15.360	15.360	16.291	16.291				
										164.55	

不二測量株式会社