



# 街角点座標及街区面積計算簿

街区番号 (No. 2756)

点	方向角(A)	距離(S)	Cos A		sin A		x	y	(3) 複緯距	(4) 複経距	(1) × (4)	(2) × (3)
			(1) S Cos A	(2) S sin A								
A <sub>1</sub>							5710.198	5365.308				
A <sub>2</sub>	227 24 16	3.550	+ 3.256	- 1.207			5707.142	5367.115				
5	177 29	62.050	+ 65.022	+ 20.127			5641.819	5346.988				
B <sub>1</sub>	17 4 02	29.422	+ 28.120	+ 8.657			5612.636	5338.331				
B <sub>2</sub>	59 26 16	3.492	+ 1.775	+ 3.007			5611.261	5335.324				
C <sub>1</sub>	107 27 57	19.331	- 5.822	+ 18.440			5617.663	5316.884				
C <sub>2</sub>	151 42 23	3.368	- 2.968	+ 1.591			5620.631	5315.293				
8	197 4 55	12.101	- 12.479	- 4.142			5624.110	5319.435				
10	197 4 4	30.020	- 28.698	- 8.211			5662.808	5328.246				
12	197 0 06	29.059	- 27.788	- 8.501			5690.596	5336.747				
D <sub>1</sub>	196 53 54	24.739	- 23.671	- 7.191			5714.267	5343.938				
D <sub>2</sub>	241 41 41	3.446	- 1.634	- 3.034			5715.901	5346.972				
A <sub>1</sub>	227 18 02	19.202	+ 5.703	- 18.336			5710.198	5365.308				
点検点座標計算										Σ		
										倍面積		
										面積		2467.261

不二測量株式会社



27BL

換地面積計算用紙 (不正形用)

角頂	夾角	辺長	方位角	緯距		経距		複経距	倍面積		町地名番
				+	-	+	-		+	-	
	(=)										
1											
2		14.589	17 7 27	10.252		4.929					
16		11.621	107 14 2		0.024	10.208					
15		14.589	127 11 3		10.207		4.910				
1		11.605	127 10 40	0.059			10.207				
				17.021	17.021	14.207	14.207			146.564	

不二測量株式会社

27BU

換地面積計算用紙 (不正形用)

角頂	夾角	辺長	方位角	緯距		経距		複経距	倍面積		町地名番
				+	-	+	-		+	-	
	(三)										
2											
3		16.712	177°28'	14.060		9.001					
17		11.425	107°25'		3.422	10.290					
16		16.407	127°10'		13.964		9.013				
2		11.421	227°14'	3.424			10.902				
				17.444	17.444	15.221	15.221			187.523	

不二測量株式会社

27BL

換地面積計算用紙  
(不正形用)

角頂	夾角	辺長	方位角	緯距		経距		複経距	倍面積		町地名番
				+	-	+	-		+	-	
	四										
0											
4		16.816	177°21'	10.777		8.085					
10		11.248	107°20'54"		0.823	10.724					
17		12.408	187°10'41"		10.282		8.279				
3		11.805	227°45'06"	0.828			10.290				
				17.266	17.266	15.109	15.109			165.047	

不二測量株式会社

換地面積計算用紙 (不正形用)

角頂	夾角	辺長	方位角	緯距		経距		複経距	倍面積		町地名番
				+	-	+	-		+	-	
	(五)										
4											
5		14.425	17 22P	10.224		4.240					
1P		11.40P	107 12 46			3.391	10.946				
18		14.462	117 10 24			13.217	4.272				
4		11.447	287 20 54	3.823			10.924				
				17.200	17.200	15.194	15.194			165.424	

不二測量株式会社

換地面積計算用紙 (不正形用)

角頂	夾角	辺長	方位角	緯距		經距		複經距	倍面積		町地名番
				+	-	+	-		+	-	
	(六)										
5											
6		15.086	17 4 02	14.669		4.502					
20		11.428	105 42 19		0.021	10.996					
19		15.427	107 10 07		14.709		4.556				
5		11.459	12 46	0.021			10.946				
				12.060	18.060	14.502	14.502			176.520	

不二測量株式会社



換地面積計算用紙 (不正形用)

角頂	夾角	辺長	方位角	緯距		経距		複経距	倍面積		町地名番
				+	-	+	-		+	-	
	(七)										
6											
B1		18.107	17 40 22	10.514		8.151					
B2		10.422	59 26 16	1.220		10.027					
7		9.163	107 27 57		2.750	2.740					
20		16.600	197 10 31		15.060		4.902				
6		11.422	226 28 19	10.022			10.996				
				10.610	10.610	10.022	10.022			100.627	

不二測量株式会社

27BL

角頂	夾角	辺長	方位角	緯距		経距		複経距	倍面積		町地名番
				+	-	+	-		+	-	
	(1)										
20											
7		16.600	17 10 31	15.260		4.900					
C1		10.160	107 27 57		0.250	9.700					
C2		0.060	151 40 20		2.900	1.500					
8		14.101	127 4 14		10.470		4.180				
20		12.500	226 40 0	0.600			12.050				
					10.400	10.400	16.100	16.100			205.013

換地面積計算用紙 (不正形用)

不二測量株式会社

角頂	夾角	辺長	方位角	緯距		経距		複経距	倍面積		町地名番
				+	-	+	-		+	-	
	(丸)										
1P											
20		15.427	17 10 37	14.73P		4.556					
0		12.528	106 48 P		0.50P	12.051					
1P		15.516	127 4 4		14.200	4.554					
1P		12.618	227 12 31	3.700		12.050					
				18.472	18.872	16.607	16.607			196.990	

換地面積計算用紙 (不正形用)

不二測量株式会社

27BL

換地面積計算用紙 (不正形用)

角頂	夾角	辺長	方位角	緯距		経距		複経距	倍面積		町地名番
				+	-	+	-		+	-	
	(+)										
12											
11		14.462	17 10 24	13.217		4.270					
10		12.618	107 12 21			2.703	12.050				
10		14.504	177 4 4			13.264	4.247				
12		12.444	287 23 56	2.781			12.066				
				17.570	17.570	16.020	16.020			182.930	

不二測量株式会社

27BL

角頂	夾角	辺長	方位角	緯距		経距		複経距	倍面積		町地名番
				+	-	+	-		+	-	
	(正)										
17											
18		18.200	17 10 41	10.252		4.279					
10		12.544	107 23 45		0.781	12.066					
11		14.540	107 0 05		10.901	4.262					
17		12.600	287 45 04	0.270		12.020					
				17.712	17.712	16.244	16.244			104.000	

換地面積計算用紙 (不正形用)

不二測量株式会社

27BL

角頂	夾角	辺長	方位角	緯距		経距		複経距	倍面積		町地名番
				+	-	+	-		+	-	
	(±)		° ' "								
10											
17		14.507	17 10 24	10.956		4.010					
11		12.607	107 45 24		0.279	12.203					
12		14.491	107 2 06		10.257	4.234					
16		12.707	107 14 0	0.271		12.157					
				17.727	17.727	16.296	16.296			124.220	

換地面積計算用紙 (不正形用)

不二測量株式会社

換地面積計算用紙 (不正形用)

角頂	夾角	辺長	方位角	緯距		経距		復経距	倍面積		町地名番
				+	-	+	-		+	-	
	(正)										
15											
16		14.588	17 11 0	12.237		4.310					
12		12.728	107 16 0		3.771	12.157					
13		14.574	176 53 54		13.267		4.237				
14		12.201	107 10 46	3.781			12.230				
				17.718	17.718	16.267	16.267			106.138	

不二測量株式会社

換地面積計算用紙 (不正形用)

角頂	夾角	辺長	方位角	緯距		経距		複経距	倍面積		町地名番
				+	-	+	-		+	-	
	(高)		° ' "								
14											
15		12.602	17 10 6	12.041		0.720					
13		12.801	107 10 46		0.781	12.239					
D1		10.160	126 50 54		0.724		0.954				
D2		0.226	241 41 41		1.604		0.004				
14		10.432	227 16 00	0.000			0.962				
				15.109	15.139	15.910	15.910			158.210	

不二測量株式会社