

15.2 BL

主任	担当	計算	点検
			







換地面積計算用紙  
(不正形用)

角頂	夾角	辺長	方位角	緯距		経距		複経距	倍面積		町地名番
				+	-	+	-		+	-	
1											二
2		13.544	27-31-06	12.012		6.257		6.257		75.159	
20		21.549	117-29-03	9.945		19.117		31.631		314.570	
21		13.550	207-27-54	12.023		6.250		44.498		534.999	
27		7.356	297-28-40	3.394		6.526		31.722		107.664	
26		8.080	297-31-22	3.734		7.166		18.030		67.324	
1		6.124	297-30-08	2.828		5.432		5.432		15.361	
										584.061	
										292.030	

不二測量株式会社

換地面積計算用紙  
(不正形用)

角頂	夾角	辺長	方位角	緯距		経距		複経距	倍面積		町地名番
				+	-	+	-		+	-	
a											三
1		15.526	27-31-06	13.769		7.174		7.174	98.778		
26		6.124	117-30-08	2.828		5.432		19.780	55.937		
18		18.009	207-24-52	15.987		8.292		16.920	270.500		
h		3.666	297-30-58	1.694		3.251		5.377	9.108		
a		3.517	342-24-18	3.352		1.063		1.063	3.563		
									214.988		
									107.494		

不二測量株式会社

換地面積計算用紙  
(不正形用)

角頂	夾角	辺長	方位角	緯距		経距		複経距	倍面積		町地名番
				+	-	+	-		+	-	
16											六
27		18.009	27-30-46	15.972		8.319		8.319	132.871		
21		7.356	117-28-40	3.394		6.526		23.164	78.618		
22		8.030	207-27-54	7.125		3.703		25.987	185.157		
15		9.983	207-32-26	8.852		4.616		17.668	156.397		
16		7.358	297-30-58	3.399		6.526		6.526	22.181		
									265.120		
									132.560		

不二測量株式会社







換地面積計算用紙 (不正形用)

角頂	夾角	辺長	方位角	緯距		経距		複経距	倍面積		町地名番
				+	-	+	-		+	-	
34											十
6		5.770	27-25-16	5.122		2.657		2.657		13.609	
d		15.108	117-30-26	6.978		13.400		18.714		130.586	
e		3.891	157-55-50	3.606		1.462		33.576		121.075	
7		3.306	197-51-07	3.147		1.013		34.025		107.076	
34		18.616	297-32-42	8.609		16.506		16.506		142.100	
										203.028	
										101.514	

不二測量株式会社

換地面積計算用紙  
(不正形用)

角頂	夾角	辺長	方位角	緯距		経距		複経距	倍面積		町地名番
				+	-	+	-		+	-	
35											
34		5.190	27-25-16	4.607		2.390		2.390		11.010	丈
7		18.616	117-32-42	8.609		16.506		21.286		183.251	
8		5.287	197-51-07	5.032		1.621		36.171		182.012	
35		19.495	297-36-27	9.034		17.275		17.275		156.062	
										198.191	
										99.095	

不二測量株式会社

換地面積計算用紙 (不正形用)

角頂	夾角	辺長	方位角	緯距		経距		複経距	倍面積		町地名番
				+	-	+	-		+	-	
36											十二
35		3.240	27-25-16	2.876		1.492		1.492		4.290	
8		19.495	117-36-27	9.034		17.275		20.259		183.019	
9		3.290	197-51-07	3.132		1.009		36.525		114.396	
36		20.041	297-36-58	9.290		17.758		17.758		164.971	
										128.154	
										64.077	

不二測量株式会社



換地面積計算用紙  
(不正形用)

角頂	夾角	辺長	方位角	緯距		経距		複経距	倍面積		町地名番
				+	-	+	-		+	-	
33											十四
37		5.856	27-25-16	5.198		2.697		2.697	14.019		
10		20.574	117-37-34	9.540		18.228		23.622	225.353		
11		5.928	197-51-07	5.642		1.817		40.033	225.866		
33		21.560	297-35-16	9.984		19.108		19.108	190.774		
									246.426		
									123.213		

不二測量株式会社

換地面積計算用紙  
(不正形用)

角頂	夾角	辺長	方位角	緯距		経距		複経距	倍面積		町地名番
				+	-	+	-		+	-	
22											十五
19		24.523	27-27-54	21.759		11.310		11.310	246.094		
31		14.259	117-45-39	6.642		12.618		35.238	234.050		
32		10.439	207-25-16	9.266		4.807		43.049	398.892		
11		32.860	117-35-16	15.217		29.124		67.366	1025.108		
f		19.826	197-51-53	18.870		6.082		90.408	1705.998		
g		5.798	247-44-04	2.197		5.366		78.960	173.475		
12		28.989	297-30-10	13.387		25.713		47.881	640.982		
25		10.006	27-25-41	8.881		4.609		26.777	237.806		
22		17.690	297-29-16	8.165		15.693		15.693	128.133		
									2284.508		
									1142.254		
									<del>209</del>		
									<u>1142.34</u>		

不二測量株式会社



換地面積計算用紙  
(不正形用)

角頂	夾角	辺長	方位角	緯距		経距		複経距	倍面積		町地名番
				+	-	+	-		+	-	
13											八
24		9.998	27-28-11	8.871		4.612		4.612	40.913		
25		5.793	117-29-16	2.674		5.139		14.363	38.406		
12		10.006	207-25-41	8.881		4.609		14.893	132.264		
13		5.800	297-33-38	2.684		5.142		5.142	13.801		
									115.956		
									57.978		

不二測量株式会社



換地面積計算用紙  
(不正形用)

角頂	夾角	辺長	方位角	緯距		経距		複経距	倍面積		町地名番
				+	-	+	-		+	-	
木		11.047	27-35-16	9.790		5.116		5.116		50.085	十五ノ一
11		16.100	117-35-16	7.455		14.269		24.501		182.654	
イ		8.164	197-51-53	7.770		2.504		36.266		281.786	
口		11.479	297-35-16	5.315		10.174		23.588		125.370	
ハ		3.000	207-35-16	2.659		1.389		12.025		31.974	
二		6.000	297-35-16	2.779		5.318		5.318		14.778	
										306.181	
										153.090	
										+ 0.02	
										<u>153.111</u>	

不二測量株式会社





換地面積計算用紙 (不正形用)

角頂	夾角	辺長	方位角	緯距		経距		複経距	倍面積		町地名番
				+	-	+	-		+	-	
( 2 )											1-1
( b )		13.154	27-31- 6	11.666	0	6.078	0	6.078	70.9059		
( c )		3.526	72-37-25	1.053	0	3.365	0	15.521	16.3436		
( 41 )		8.465	117-30-43	-3.910	0	7.508	0	26.394	-103.2005		
( 42 )		15.638	207-27-54	-13.875	0	-7.212	0	26.690	-370.3237		
( 2 )		10.978	297-29- 3	5.066	0	-9.739	0	9.739	49.3377		
								BAIMENSEKI	-336.9370		
								MENSEKI	168.46		
									<del>+0.02</del>		
									<u>168.48</u>		

不二測量株式会社

換地面積計算用紙 (不正形用)

角頂	夾角	辺長	方位角	緯距		経距		複経距	倍面積		町地名番
				+	-	+	-		+	-	
( 42 )	)										1-2
( 41 )	)	15.638	27-27-54	13.875	0	7.212	0	7.212	100.0665		
( 43 )	)	5.574	117-30-43	-2.575	0	4.944	0	19.368	-49.8726		
( 44 )	)	15.635	207-27-54	-13.873	1	-7.211	0	17.101	-237.2250		
( 42 )	)	5.574	297-29-3	2.572	0	-4.945	0	4.945	12.7185		
								BAIMENSEKI	-174.3126		
								MENSEKI	87.15		

不二測量株式会社

換地面積計算用紙 (不正形用)

角頂	夾角	辺長	方位角	緯距		経距		複経距	倍面積		町地名番
				+	-	+	-		+	-	
44	)										1-3
43	)	15.635	27-27-54	13.873	0	7.211	0	7.211	100.0382		
3	)	4.997	117-30-43	-2.308	0	4.432	0	18.854	-43.5150		
20	)	15.633	207-27-54	-13.871	0	-7.210	0	16.076	-222.9901		
44	)	4.997	297-29-3	2.306	0	-4.433	0	4.433	10.2224		
								BAIMENSEKI	-156.2445		
								MENSEKI	78.12		

不二測量株式会社

換地面積計算用紙 (不正形用)

角頂	夾角	辺長	方位角	緯距		経距		複経距	倍面積		町地名番
				+	-	+	-		+	-	
18	)										4
26	)	18.009	27-24-52	15.987	0	8.292	0	8.292	132.5642		
27	)	8.080	117-31-22	-3.734	0	7.166	0	23.750	-88.6825		
16	)	18.009	207-30-46	-15.972	0	-8.319	0	22.597	-360.9192		
18	)	8.050	297-30-58	3.719	0	-7.139	0	7.139	26.5499		
								BAIMENSEKI	-290.4876		
								MENSEKI	145.24		
									<u>-0.01</u>		
									145.23		

不二測量株式会社

換地  
面積  
計算  
用紙  
(不正形用)

角頂	夾角	辺長	方位角	緯距		経距		複経距	倍面積		町地名番
				+	-	+	-		+	-	
40	)										16-1
22	)	7.333	27-32-26	6.502	0	3.391	0	3.391	22.0482		
23	)	5.244	117-29-16	-2.420	0	4.652	0	11.434	-27.6702		
14	)	9.990	207-30-23	-8.861	1	-4.614	1	11.473	-101.6507		
39	)	4.250	297-33-38	1.966	0	-3.768	0	3.092	6.0788		
39	)	2.650	27-32-26	2.350	0	1.225	0	0.549	1.2901		
40	)	1.000	297-32-26	0.462	0	-0.887	0	0.887	0.4097		
								BAIMENSEKI	-99.4941		
								MENSEKI	49.74		

不二測量株式会社

換地面積計算用紙 (不正形用)

角頂	夾角	辺長	方位角	緯距		経距		複経距	倍面積		町地名番
				+	-	+	-		+	-	
( 15 )											16-2
( 40 )		2.650	27-32-26	2.350	0	1.225	0	1.225		2.8787	
( 39 )		1.000	117-32-26	-0.462	0	0.887	0	3.337		-1.5416	
( 38 )		2.650	207-32-26	-2.350	-1	-1.225	0	2.999		-7.0506	
( 15 )		1.000	297-33-38	0.463	0	-0.887	0	0.887		0.4106	
								BAIMENSEKI		-5.3029	
								MENSEKI		2.65	

不二測量株式会社